

| | | |
|--|---|---|
| Menu Enter ▲► → ? Menu Exit ▲► → EE | ◀► Send MYCALL ◀▼ Decr. QSO# → EE ▼► Send Speed | ◀▲ Enter TUNE mode ▲▼◀► Exit TUNE mode |
| Record Message ▲▼◀► 1s → K Key message ▲▼◀► short to review ▲▼◀► long to store | Menu Items ▲▼ to change S Speed Q QSO Nr. RL Speed low RH Speed high X Cut nums L letter spac. Z Lead 0 B Beacon dly W Weight T Sidetone K Keymode P paddle rev A Tonehgt D TX comp Y ▼ MYCALL #1 Y ▲ MYCALL #2 MENU long/short text V Version | MEMORY SHORTS // "/" /R Repeat word /1234 Send Msg# /QI QSO# + incr /QN QSO# /QR Last QSO# /SU Inc speed /SD Dec speed /Y Send MYCALL #1 /Y2 Send MYCALL #2 |